


Cruciform Foyer SRm 1-3 : AV Quick Start Guide

To turn on the display

- Press the On/Off Button on the right hand side of the Display (As below)
- 1 On/Off button
 - 2 Prowise Central Home button
 - 3 USB 3.0
 - 4 Status LED charging station
 - 5 Charging station / ProWrite Ink pen

Right: Side of Prowise Display



Using the resident PC (Desktop @ UCL)

- Once the display is fully powered up, the display will default to the D@U PC
- Use the Keyboard/Mouse or Prowise Touchscreen Display for control.

Touchscreen Control

	Click	To click on a part of the screen, gently tap with one finger on the touchscreen.
	Drag	Tap with one finger on the item that you want to move and drag it to the new location without releasing your finger from the screen.
	Open Prowise Central menu	Place five fingers of one hand on the screen for at least 2 seconds. The menu will appear.
	Right-click (context-menu) (PC module)	Tap and hold one finger on the screen for a few seconds for the right click function.
	Scroll	Slide one finger across the screen in the desired direction.

.....PTO


To Connect a Laptop

- Please connect the HDMI lead connected to the Display.
- The Display will auto switch to the correct input (**HDMI1**)

To Switch Input (PC, Laptop HDMI, Wireless presentation Device)

- Perform a 5 finger press of the display, for 3 seconds
- Using the touchscreen display menu press button 4 (as below)

1. Prowise Central Home
2. Volume settings
3. ProNote
4. Change input source
5. Menu button



- For **PC**, select **PC** from the slide out menu.
- For **Laptop HDMI**, select **HDMI 1** from the right hand slide out menu.
- For **Wireless**, select **HDMI 2** from the right hand slide out menu.

To Connect to the Wireless Presentation Device

- Whilst connected to Eduroam, open a browser window
- Input the IP address displayed on screen into your browser URL field
- Follow instructions and enter the unique 4 digit code displayed on Display

To Adjust Volume

- Perform a 5 finger press of the display, for 3 seconds
- Press Speaker Icon for Volume Settings
- Adjust volume using onscreen touch control

NB. Please note volume can also be adjusted on your personal device or via the Windows volume control on the resident PC.

Relocating the Mobile Display

- Disconnect 1No power and 4No colour-coded network cables
- Relocate the display to the the secondary position in room
- Reconnect colour coded cables to each colour coded port.
- Connect 1No power lead.